





电性参

Absolute Maximum Rating

光电参数

Ta=25

Optical-electrical parameter













焊接指导 (2)

Guideline for Soldering (2)

2. Note:

Cleaning

30

30

3

50

LED

300W

LED

LED

It is recommended that alcohol be used as a solvent for cleaning after soldering. Cleaning is to go under 30 for 3 minutes or 50 for 30 seconds. When using solvents, it should be confirmed beforehand whether the solvents will damage the package and the resin or not.

Ultrasonic cleaning is also an effective way for cleaning. But the influence of Ultrasonic cleaning on the package factors such as ultrasonic power. Generally, the ultrasonic power should not be higher than 300W. Before cleaning, a pre-test should be done to confirm whether any damage to LEDs will occur.

* 注意:

PCB

* **Note:** This general guideline may not apply to all PCB designs and configurations of all soldering equipment. The technique in practice is inf



Doc. No. : VI-1808HCC-06A
~~Doc. No. : VI-1808HCC-06A~~





