Part

## 可靠性试验

Reliability Test Items And Conditions

| Class | Test item | Testing environment |
|---|---|---|

# 包装（1）

## Packaging (1)







:

1. ㄧ β ㄣ (mm) Á

1. Size unit is mm (mm).

2. `E ±0.1mm Â

2. The dimensional tolerance is ± 0.1mm.